



## FS330W TCP/IP CENTER MONITOR



The console via USB cable to FS330W PC software  
The console via IP/Wi-Fi and network to Web Server



Console report all event to center monitor  
Center can setting console working mode  
Center can setting console alarm function  
Center save alarm event for view log

### ● Applications:

The FS330W software is designed for PC window OS system connecting to alarm console via IP or USB port, so that PC window software can operate alarm console working mode and control the AC power switch on/off and setting the alarm function. The FS330W software is designed for Saving/Loading a txt file of the setting program data.

It can also READ/WRITE the setting program data from alarm console.

It can show all alarm events, working mode, temperature lever data, AC power switch turn on number...etc.

## ALARM CENTER MONITOR FUNCTION

FS330W\_PC\_V1.8-test

# FRONTI

## FS330W ALARM SERVICE CENTER SYSTEM

### EVENT MONITOR, CONTROL AND SETTING CENTER

TCP/IP Mode    IP Address: 114.32.51.39    PASSWORD: [Yellow Box]

Not Connected    Port: 23

[MONITOR]   [SWITCH]   [SECURITY]   [SETUP]   [EXIT]

SCAN

FW Ver.

## RECEIVER ALARM EVENT LOG ON PC

FS330W\_PC\_V1.87

DISARM 1-13
INT : \*\*\*\*
EXT : \*\*\*\*
POWER SWITCH ON : -

DISARM 2-13

No.	Date	Time	ALARM	Sensor No.	Sensor Name
55	05 / 23	16 : 33	HOME 2	10 - 15	
56	05 / 23	16 : 33	HOME 1	10 - 15	
57	01 / 01	00 : 00	TAMPER ERROR	00 - 00	
58	01 / 01	00 : 00	DISARM 2	01 - 00	
59	01 / 01	00 : 00	DISARM 1	01 - 00	
60	01 / 01	00 : 00	TAMPER ERROR	00 - 00	
61	01 / 01	00 : 00	TAMPER ERROR	00 - 00	
62	01 / 01	03 : 20	OPEN SENSOR	74 - 00	
63	01 / 01	03 : 20	OPEN SENSOR	75 - 00	
64	01 / 01	03 : 20	OPEN SENSOR	76 - 00	
65	01 / 01	03 : 19	OPEN SENSOR	77 - 00	
66	01 / 01	03 : 19	OPEN SENSOR	78 - 00	
67	01 / 01	03 : 19	OPEN SENSOR	79 - 00	

MONITOR
SWITCH
SECURITY
SETUP
SYSTEM

## SETUP ALARM CONSOLE WORKING MODE

FS330W\_PC\_V1.86

DISARM 1-10
INT : +19°C
EXT : +21°C
POWER SWITCH ON : -

HOME 2-10

AWAY

PANIC

S.L PANIC

GSM LEVER

← \*\*\*\*

HOME

FIRE

MEDICAL

FS132 OPEN

1

2

3

DISARM

ALARM OFF

TIMER : OFF

WORKING DAY

DISARM : 24:00

HOME : 24:00

AWAY : 24:00

4

5

6

HOLIDAY

DISARM : 24:00

HOME : 24:00

AWAY : 24:00

7

8

9

HOLIDAY

1

2

3

4

5

6

7

CE

0

#

MONITOR
SWITCH
SECURITY
SETUP
SYSTEM