

Key fob list

Item	1	2	3	4	5	6	7	8	9	
ABS	Image									
	Model. No.	AB0000	AB0001	AB0003	AB0005	AB0006	AB0010	AB0016	AB0020	AB0021
	Frequency	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF

Item	1	2	3	4	5	6	
PVC	Image						
	Model. No.	PV0001	PV0002	PV0003	PV0004	PV0006	PV0022
	Frequency	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF

Item	1	2	3	4	5	6	7	8
PVC + Epoxy	Image							
	Model. No.							
	Frequency	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF

Item	1	2	3	4	5	6	7	
PC	Image							
	Model. No.	KTU	KU6	KSU	KWU	KP6	KP6	KO6
	Frequency	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF

Item	1	2	3	4	5	6	7	8	9	
FR4	Image									
	Model. No.	FAJ	FBJ	FCJ	FUJ	FPJ	FQJ	FRJ	FSJ	FTJ
	Frequency	HF	HF	HF	HF	HF	HF	HF	HF	HF

Item	1	2	3	4	5	
Faux Leather	Image					
	Model. No.	PJ0001	PJ0002	PJ0003	PJ0004	PJ0005
	Frequency	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF

Item	1	2	3	4	5	6	
Genuine Leather	Image						
	Model. No.	PJG001	PJG002	PJG003	PJG004	PJG005	PJG006
	Frequency	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF	LF/HF

Item	1	2	
Premier Genuine Leather	Image		
	Model. No.	KMN	KMM
	Frequency	LF/HF	LF/HF

Item	1	2	
Others	Image		
	Material	Nylon	Plastic Steel (POM)
	Frequency	LF/HF	LF/HF